



**iwata** *studio series*

**SILVER JET IS-50**

**AIR COMPRESSOR**

**iwata** *studio series*  
*Silver Jet*




**IWATA STUDIO SERIES SILVER JET AIR COMPRESSOR — IS-50**


*Congratulations on your new purchase! The Iwata Silver Jet Air Compressor has been designed for users who need quiet, clean, pulse-free air with precise adjustment of air pressure to the airbrush.*



Features:

- Oil-Less Piston Compressor
- Air Pressure Adjustment Knob
- Air Pressure Gauge
- Airbrush Holder
- Cord Wrap
- On/Off Switch
- Protective Metal Case
- Pistol-Grip Filter





## The Pistol-Grip Filter

is included with

the Iwata Studio

Series Silver

Jet Compressor.

**iwata**  
MEDEA

## ***Pistol-Grip Filter***

*For clean, dry air-flow.*

Attaching directly onto the airbrush, the Iwata-Medea Pistol-Grip Filter is the final defense to deliver clean, dry air to your airbrush. Miniature in size, the super-fine, 5-micron filter element performs like a full-size moisture separator.

The clear filter bowl allows a visual inspection of built-up moisture and is evacuated through a spring-loaded release valve – without taking the filter off the airbrush.

Ergonomically designed, the Pistol-Grip Filter provides for many comfortable hours of spraying.

40

## GETTING STARTED

1. Unpack the compressor and all packaged components. Enclosed you'll find:
  - a. Silver Jet Compressor (#IS-50)
  - b. Coiled Air Hose
  - c. Pistol-Grip Filter (#F A450)
  - c. Silver Jet Manual

2. Screw the Pistol-Grip Filter onto the airbrush. Finger tighten only. (Image 1)

- a. The Pistol-Grip Filter fits Iwata airbrushes only.

3. Screw the airhose onto the Pistol-Grip Filter. (Image 2)

- a. Airhose fits Pistol-Grip Filter and Iwata airbrushes only.



Image 1



Image 2

## GETTING STARTED (CONTINUED)

4. Screw the airhose onto the compressor. (Image 3)
  - a. Other brands of airbrush hoses will fit the compressor. (both have 1/4" threads)
5. Press down on the airbrush trigger before turning on the unit. (Image 4)



Image 3



Image 4

## GETTING STARTED (CONTINUED)

6. Plug the unit into a grounded wall outlet. Turn ON the unit by pressing the top side of the switch. (Image 5) Adjust the air pressure by turning the air adjustment knob to the desired pressure. Turn knob toward + to increase pressure and toward - to decrease pressure. Max pressure is 18 psi.
7. As the unit is being used, water may collect in the Pistol-Grip Filter. Release the water by pushing up on the release valve (small pin) with your finger and a paper towel while the unit is turned on. (Image 6)



Image 5



Image 6

- When not using your airbrush, place the front of the airbrush into the holder.  
(Image 7)



Image 7

9. When storing your Silver Jet, you can use the cord wrap feature around the base of the unit. (Image 8)
10. **Note on voltage:** If you bought the compressor in the country you're going to use it, it's completely ready to go. If you're going to transfer the compressor to another country with a different voltage, you'll need a plug adapter and the appropriate power converter. These items typically are found at hardware stores or electronic stores.



Image 8

All Iwata compressors are *Warranted* against all manufacturing defects of material and manufacture or workmanship for a period of ONE year from the date of purchase\*. Any part or material that is or becomes defective so as not to be usable within this period will be repaired or replaced. This warranty does not cover damage caused by negligence or a compressor that has been altered or abused in any way.

Call or email Iwata-Medea before returning a compressor for the appropriate procedure for warranty repairs. Any material that is shipped to Iwata-Medea without prior authorization will not be accepted.

- Telephone Technical Support: Iwata-Medea offers technical support over the phone at no charge. Telephone support includes general usage information, cleaning tips, and troubleshooting.
- For Tech Support please call us at 503-253-7308 Pacific Time, 9am – 12pm & 1pm – 4pm, Monday – Friday
- NOTE: All compressors returned for repair must have a Return Authorization Number. Please call 503-253-7308 to obtain an RA number, instructions, and our shipping address.

Warranty service will be provided only at authorized Iwata-Medea service centers. You must pay all charges for shipping/transporting your Iwata Studio Series Compressor to/from these service facilities.

*Iwata-Medea, Inc will not be responsible for damage to persons or property, commercial loss or any other incidental or consequential damage caused by a defective compressor. However, some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.*

*All implied warranties, including any warranty of merchantability or fitness are limited to the duration of this written warranty. However, some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.*

\* Please keep the sales receipt.

*Genuine Iwata*



— W W W . I W A T A A I R B R U S H . c o m —

**Iwata-Medea, Inc.** • 1336 N. Mason St. • Portland, Oregon 97217

tel: (503) 253-7308 • fax: (503) 253-0721 • [info@medea-artool.com](mailto:info@medea-artool.com)